



6658R und 6658P

Wegen ständigen Produktverbesserungen dienen die hier gezeigten Zeichnungen und Beschreibungen nur zur Orientierung und können ohne Vorankündigung geändert werden.

		<p>Verzinkte Stahlseilkausche (DIN6899A) für Stahldrahtseile von Ø 3 bis 3,5mm (Packeinheit 20Stk.)</p>	<p>6658RT034Z</p>
		<p>Verzinkte Seilklemme für Stahldrahtseile Ø 3 bis 3,5mm (Packeinheit 10Stk.)</p>	<p>6658RC036Z</p>
		<p>Verzinkte Wandhalterung für die Typen 58Z und 58L (Packeinheit 1Stk.)</p>	<p>6658RW035Z</p>
<p>1 Check the release printed on the product (58Z or 58L). Secure the line with this pin before and do not try glass bulb replacement. 2 Remove the screw with hexagonal key wrench. Size is 2.5mm for 58L, and 5.6 mm (3.17mm) for 58Z. Remove the old glass bulb. 3 Put new pin in a new glass bulb to make (Dia. 5 mm for 58Z or Dia. 2mm for 58L). Put the screw and tighten right to the mark. Do not break the bulb if you need. If you break, change the bulb inside and do with a small force driver, and check visually that the filling inside is not leaked. Do not risk to click again the case after re-connection.</p>		<p>Verriegelungs- stift zum Auswechseln von Glaskolben (Packeinheit 1Stk.)</p>	<p>6658PG001Z</p>
		<p>Edelstahlhalterung für die seitliche Montage der Typen 59A7 und 59B7 (Packeinheit 1Stk.)</p>	<p>6659RW035Z</p>